

THE SHOOTER FAMILY - TASCHENMATRIX

	Julia Shooter L	Julia Shooter M	Steve Shooter L	Steve Shooter M	Mary Shooter L	Mary Shooter M
Kamerafach innen (cm)	24 x 18 x 40	19,5 x 16 x 39,5	21,5 x 13 x 19	18,5 x 11 x 15,5	10,5 x 3,0 x 6,5	10,5 x 3,0 x 6,5
CANON						
EOS 450D & 18-55	✓	✓	✓	✓		
EOS 450D & 18-200	✓	✓	✓			
EOS 450D & 17-85	✓	✓	✓	✓		
EOS 450D & 17-85 + 70-300	✓	✓				
EOS 450D & 18-55 + 55-250	✓	✓				
EOS 500D	✓	✓	✓	✓		
EOS 550D & 18-55	✓	✓	✓	✓		
EOS 550D & 18-135	✓	✓	✓			
EOS 1000D & 18-55	✓	✓	✓	✓		
EOS 1000D & 18-55 + 75-300	✓	✓				
EOS-1D Mark IV	✓	✓	✓			
EOS 5D MARK II	✓	✓	✓			
EOS 5D Mark II & 24-105	✓	✓	✓			
EOS 50D & 17-55	✓	✓	✓			
EOS 50D & 17-85	✓	✓	✓			
EOS 50D & 18-200	✓	✓	✓			
EOS 50D & 17-85 + 70-300	✓	✓				
EOS 7D	✓	✓	✓			
IXUS 95 IS / 100 IS / 105 / 120 IS / 130						
IXUS 110 IS / 200 IS / 210					✓	
POWERSHOT A480 / A490 / A495					✓	
POWERSHOT A1100 IS / A2100 IS					✓	
POWERSHOT A3000 IS / A3100 IS					✓	
POWERSHOT S90					✓	

POWERSHOT SX210 IS					✓	
CASIO						
Exilim Zoom EX-FC100						
Exilim EX-FH100					✓	
Exilim EX-H10 / EX-H15					✓	
Exilim Card EX-S12						
Exilim Zoom EX-Z2 / EX-Z33 / EX-Z90						
Exilim Zoom EX-Z270 / EX-Z280					✓	
Exilim Zoom EX-Z400 / EX-Z450 / EX-Z550					✓	
Exilim EX-Z2000					✓	
FUJIFILM						
FinePix F70EXR / F80EXR					✓	
FinePix F200EXR					✓	
FinePix HS10				✓		
FinePix J27 / JV100 / JX200						
FinePix JZ300 / JZ500					✓	
FinePix XP10					✓	
FinePix Z30 / Z33WP					✓	
FinePix Z35 / Z37 / Z70 / Z300						
FinePix Z700EXR					✓	
HYUNDAI						
A1227 / A9324					✓	
L5100s						
S5027 WP						
NIKON						
D3			✓			
D3s			✓			
D300 & 16-85			✓			
D300 & 18-200			✓			
D3000 & 18-55			✓	✓		
D3000 & 18-105			✓	✓		

D3000 & 18-55 VR + 55-200	✓	✓				
D5000 & 18-55			✓	✓		
D5000 & 18-55 + 55-200	✓	✓				
D5000 & 18-105			✓			
D5000 & 18-105 + 70-300	✓	✓				
D5000 & 18-200			✓			
D700 + MB-D10						
D700 & 24-120 + MB-D10	✓	✓				
D90 16-85			✓			
D90 & 18-105			✓			
D90 & 18-105 + 70-300	✓	✓				
D90 & 18-200			✓			
Coolpix L20 / L21 / L22					✓	
Coolpix S60 / S70					✓	
Coolpix S220 / S230 / S550 / S570 / S610						
Coolpix S610c					✓	
Coolpix S620 / S640						
Coolpix S1000pf					✓	
Coolpix S3000 / S4000						
Coolpix S8000					✓	
OLYMPUS						
E-3 & Batteriegriff HLD-4			✓			
E-3 & 14-54			✓	✓		
E-3 & 12-60 + Power Grip HDL-4			✓			
E-30 & 14-42			✓	✓		
E-30 & 12-60			✓	✓		
E-520 & 14-42 + 70-300	✓	✓				
E-620 & 14-42			✓			
E-620 & 14-42 + 40-150	✓	✓				
FE-26 / FE-46					✓	
FE-4000 / FE-5030						
MJU 5000 / 9000					✓	
MJU 5010						
MJU TOUGH 3000 / 6000 / 6010 / 8000					✓	

MJU TOUGH 6020 / 8010					✓	
MJU 7010 / 7040 / 9010					✓	
PANASONIC						
Lumix DMC-FS6EG / FS7EG / FS15EG					✓	
Lumix DMC-FS10EG / FS11EG					✓	
Lumix DMC-FS20EG						
Lumix DMC-FS25EG					✓	
Lumix DMC-FS30EG / FS33EG / FS62EG					✓	
Lumix DMC-FT1EG / FT2EG					✓	
Lumix DMC-FP1EG					✓	
Lumix DMC-FP8EG					✓	
Lumix DMC-FX40EG						
Lumix DMC-FX60EG / FX66EG					✓	
Lumix DMC-FX550EG						
Lumix DMC-TZ6EG / TZ7EG / / TZ8EG / TZ10EG					✓	
Lumix DMC-ZX1EG / ZX3EG					✓	
PENTAX						
K-7 & 18-55			✓			
K-7 & 18-55 + 50-200	✓	✓				
K-x & 18-55			✓			
K-x & 18-55 +50-200	✓	✓				
Optio E80 / E85 / E90					✓	
Optio H90						
Optio I-10					✓	
Optio M85						
Optio P70 / P80					✓	
Optio W80					✓	
Optio WS80						
PRAKTICA						
DCZ 8.3						
DCZ 10.4						
luxmedia 10-TS					✓	

luxmedia 10-23						
luxmedia 1203						
RICOH						
Caplio R10					✓	
GR Digital 3					✓	
Caplio CX1 / CX2 / CX3					✓	
SAMSUNG						
D70					✓	
ES10 / ES15						
ES17 / ES20					✓	
ES55 / ES60 / ES65 / ES70						
IT100						
PL50 / PL51 / PL55 / PL60 / PL65 / PL70						
PL 80 / PL100 / PL150					✓	
ST45					✓	
ST60 / ST70						
ST500 / ST550 / ST1000					✓	
WB600 / WB650 / WB1000					✓	
SONY						
Alpha 230 Kit 18-55			✓	✓		
Alpha 230 Kit 18-200			✓			
Alpha 330 Kit 18-55			✓	✓		
Alpha 330 Kit 18-55 + 55-200	✓	✓				
Alpha 380 Kit 18-55			✓	✓		
Alpha 380 Kit 18-55 + 55-200	✓	✓				
Alpha 380 Kit 18-200			✓			
Alpha 450 Kit 18-55			✓	✓		
Alpha 450 Kit 18-55 + 55-200	✓	✓				
Alpha 500 Kit 18-55			✓	✓		
Alpha 500 DZ Kit 18-55 + 55-22	✓	✓				
Alpha 550 Kit 18-55mm			✓	✓		
Alpha 550 DZ Kit 18-55 + 55-200	✓	✓				

Alpha 850 Kit 28-75mm			✓			
Alpha 900 Body			✓			
Cyber-shot DSC-H55					✓	
Cyber-shot DSC-HX5V					✓	
Cyber-shot DSC-T90 / T900					✓	
Cyber-shot DSC-TX1 / TX5 / TX7						
Cyber-shot DSC-S930 / S2000					✓	
Cyber-shot DSC-W180 / W190						
Cyber-shot DSC-W210 / W220 / W230						
Cyber-shot DSC-W270 / W290						
Cyber-shot DSC-W310 / W320 / W350 / W380						
Cyber-shot DSC-WX1						